


I/Stat Operation Instructions



If light is out press the On/Off button once to turn on AC for 2 hours.

ATTENTION: Unit must be in Occupied State to cool or heat the room to the desired "SET TEMP"

Shown is an I/Stat in a normal operating condition while in an Occupied State. The red circle to the left of the "ON/OFF" button being lit indicates that the device is in an occupied state. The "72.5" displays the room temperature when the red circle beside "ROOM TEMP" is lit.

Setpoint Adjustment: press a button greater than 8 seconds to adjust the setpoint

Setpoint 32 degrees Fahrenheit to 98 degrees Fahrenheit